


More info: see www.controlallwireless.com or email sales@controlallwireless.com



Note: Blue and white wires both go to battery ground.

Black wire from relay harness will correspond to the wire on the receiver in which you want to control the engine kill switch.

Yellow wire is connected to the engine kill switch

Center pin (red wire) not used remove wire or tuck and tape